

KIT BRONZINE



Lombardini

Modello	Misure	Codice PRAI	Rif.orig.
6LD	STD	KIT6BRONZSTD	1640.082 + 1611.018 + 1611.012
	0,25	KIT6BRONZ025	1640.083 + 1611.018(0,25) + 1611.228
	0,50	KIT6BRONZ050	1640.084 + 1611.019 + 1611.013
3LD	STD	KIT3BRONZSTD	1640.027 + 1611.221 + 1611.217
	0,25	KIT3BRONZ025	1640.028 + 1611.222 + 1611.218
	0,50	KIT3BRONZ050	1640.029 + 1611.223 + 1611.219
4LD640 - LDA96 - LDA97 - LDA100 - 4LD705	STD	KIT46BRONZSTD	1640.024 + 1610.009 + 1610.025
	0,50	KIT46BRONZ050	1640.026 + 1610.058 + 1610.057
4LD820	STD	KIT48BRONZSTD	1640.045 + 1610.009 + 1610.025
	0,50	KIT48BRONZ050	1640.049 + 1610.058 + 1610.057
LDA914 - 8LD600/2 - 8LD665/2 - 8LD665-2/L - 8LD740/2 - 8LD740-2/L	STD	130252K	1640.040 + 1611.131 + 1610.082 + 1611.147
	0,25	130253K	1640.052 + 1611.132 + 1610.098 + 1611.149
	0,50	130254K	1640.053 + 1611.133 + 1610.099 + 1611.148